

Cleaning Instructions:

Upholstery Cleaning Codes:

S

Only mild pure water-free dry cleaning solvents may be used for cleaning this fabric. Cleaning by a professional service is recommended.

W

Clean only with water based shampoo or foam upholstery cleaner. Cleaning by a professional service is recommended.

WS

Water based cleaning agents and foam may be used for cleaning. This fabric may also be cleaned with mild, water-free solvents. Cleaning by a professional service is recommended.

D

Dry clean only. Cleaning by a professional service is recommended.

Cubicle Curtain Laundering: All Arc-Com Med-Arc Cubicle fabrics are made of 100% FR polyester or Trevira CS polyester and are washable as follows:

Wash Cycle:

Process as ordinary colored fabric. Temperature should not exceed 160 degree F. Use synthetic detergent and add softener to the last rinse. Do Not Use Caustic Soap or Bleach.

Extracting Cycle:

Fabric requires no more than 2-4 minutes of extracting depending on the size of the load and equipment used. Do **Not** Put Through Mangler.

Drying Cycle:

Do not overload dryer. Tumble dry 3-5 minutes on synthetic cycle. As with all polyester, excessive heat will detract from the permanent press characteristics of this fabric. Remove immediately after completion of drying cycle.